

Cutting Tips for Flush & Corner Install

Use 10" or 12" miter saw with the appropriate blade. We recommend the Freud Diablo series for cutting non-ferrous/plastic material; specifically the 10" 80 or 84 tooth blade or the 12" 96 tooth blade.

